






Frese S

Mounting instructions


Frese A/S Tlf.: +45 58 56 00 00




Flow Frese S, DN 15




Flow Frese S, DN 20




Flow Frese S, DN 25



Flow Frese S, DN 32



Flow Frese S, DN 40



Flow Frese S, DN 50

